



EAGLE P178

WORLDWIDE FLEET MANAGEMENT



FAIL-SAFE AUDIO MIXER

The P178 Audio Mixer provides 3 Composite Outputs from up to 8 Input Signals. Channel 1 and Channel 2 Composite Outputs are Failsafe Relay Protected for Master Caution or Essential Tones to ensure that no fault in the system or an electrical bus failure can prevent pass through of Essential Warnings or Tones. Channels 3 through 8 are for non-essential tones and will drop off line in case of fault or Avionics Bus failure.

The P178 removes the need for external relays to ensure Essential Tones are passed to unswitched inputs on any audio system. The unit also has internal fault detection. Upon fault, the relays go to their normally closed (Failsafe) position. The unit also has a pull low line on fault if an external fault indicator is desired.

EAGLE AUDIO

79 AVIATION DRIVE, COFFS HARBOUR NSW 2450, AUSTRALIA

PHONE: 61.2.6690.3300 | eaglecopters.com.au



FAIL-SAFE AUDIO MIXER

Specifications

| | |
|------------------------|---|
| Number of Inputs | 8 each Balanced @ 600 Ohm Impedance |
| Number of Outputs | 3 each Composite @ 600 Ohm transformer coupled. Two are relay protected channels. |
| Input Gain Adjustment | -17dB to +10dB |
| Output Gain Adjustment | -6dB to +6dB |
| Output Signal | 150mW into 600 Ohms nominal |
| Output Current Limit | 20mA |
| Voltage (Start) | 20 VDC |
| Voltage (Hold) | 12 VDC |
| Voltage (Max) | 32 VDC |
| Power | 250 mA |
| Temperature | - 40 to 80C |
| Finish | Gold Iridite per MIL-C-5541 Class 1A |
| Weight | 225 grams. |
| Size | 7.7 W x 14.6 L x 2.7 H cms less protrusion of connector. |

Certification

| | |
|------------------------|---|
| FAA/ PMA STC SR02445SE | AS350B, BA, B1, B2, C, D, D1. AS355E, F, F1, F2, N, NP. EC130B4, T2. EC-135P1, P2, P2+, T1, T2, T2+. Bell 206A, A-1, B, L, L-1, L-3, L-4. Bell 407. |
| FAA/ PMA STC SR02444SE | MBB-117 (EC145) A-1, A-3, A-4, B-1, B-2, C-1, C-2, D-2. Bell 212, 412, 412EP, 412CF, 204B, 205A-1, B, 214B, B-1, 214ST. |
| Canada STC SH-09-17 | AS350B, BA, B1, B2, C, D, D1. AS355E, F, F1, F2, N. EC-135P1, P2, P2+, T1, T2, T2+. Bell 206A, A-1, B, L, L-1, L-3, L-4. Bell 407. |
| Canada STC SH-14-33 | MBB-117 (EC145) A-1, A-3, A-4, B-1, B-2, C-1, C-2. Bell 212, 412, 412EP, 412CF, 204B, 205A-1, B, 214B, B-1, 214ST. |
| EASA STC 10036806 | AS350B, BA, B1, B2, B3, C, D, D1. AS355E, F, F1, F2. Bell 407. |
| Brazil CHST 2007S06-30 | AS350B, BA, B1, B2, C, D, D1. AS355E, F, F1, F2. EC130B4, T2. EC-135P1, P2, P2+, T1, T2, T2+. BO-105A, C, LS A-1, LS A-3, S. Bell 206A, A-1, B, L, L-1, L-3, L-4. Bell 407. MBB-117 (EC145) A-1, A-3, A-4, B-1, B-2, C-1, C-2, D-2. Bell 212, 412, 412EP, 412CF, 204B, 205A-1, B, 214B, B-1, 214ST. |

EAGLE AUDIO

79 AVIATION DRIVE, COFFS HARBOUR NSW 2450, AUSTRALIA

PHONE: 61.2.6690.3300 | eaglecopters.com.au